SANITEN INC.

www.saniten.ca

PRODUCT:

CEMENT GROUT COLORANT – Stain Resistant

DESCRIPTION

Classification: paint WHMIS: D-2B Grout colorant for cement grout joints.

TECHNICAL DATA:

Water based acrylic product Walls and floors applications Makes grout joints stain resistant. Restrictions for counter top applications *

ENVIRONMENTAL DATA:

VOC: N/A. Biodegradability: N/A.

APPLICATIONS:

Specifically formulated for coloring cement grout on floors and walls To restore original color To correct grout color after grout application To change grout color Interior applications

RESTRICTIONS:

*The colorant may be applied on kitchen counters. However you must make sure that the cleaning products used won't damage the colorant like certain cleaners containing glycols, abrasives or other chemicals. It is recommended to apply a coat of SANITEN Grout Sealer S100 on colored grout joints of high traffic or heavily used areas to protect the lifespan of the colorant.

**The colorant is not designed for applications on epoxy grout. Furthermore, you will have to respect the required grout curing time before applying the colorant on the joints as per grout manufacturer recommendations. Usually 7 to 28 days.

*** Wait 15 to 28 days before washing the colored surface.

**** Applications in humid areas such as saunas and public showers is not recommended

DIRECTIONS :

CAUTION: It is required to test first the product on a small and adequate area to make sure that there are no incompatibilities between the product and the material on which the product is to be used on and therefore determine suitability and that result will meet consumer's expectations.

It is also required to always protect the neighboring area against unexpected contact with the product used (spills, splashes, etc) in order to prevent that surrounding material would be irreversibly altered and restored only by its replacement. Product should be used at room temperature, between 10 and 25°C

First, deep clean surface with the appropriate SANITEN cleaner or remover. Follow directions in regards with the level of cleaning or removing required.

New grout: Wait 7 to 14 days before applying colorant or as per grout manufacturer's recommendation.

Clean grout prior to colorant application with SANITEN Grout & Tile Cleaner N305, as per directions

Old grout: Remove all existing sealer, protector or dirt with appropriate SANITEN cleaner and/or remover.

-Water base sealer: use SANITEN Heavy Duty Cleaner / Water based sealers Remover PD1010

- Solvent base sealer: use SANITEN Solvent Based sealers Remover PD1350

Shake well bottle before use

Wearing of gloves and safety glasses is recommended during application

Remove the seal and cut the tip of the spout. Spread evenly adjusting spout and using a small artist paint brush Application of 1 thin coat is usually enough

Porous tiles: wipe excess on tiles with a damp cloth as soon as the colorant on the joints is dry.

Glazed and dense tiles: you can wait 24 hours to remove excess on tiles. Use a damp cloth or a rough sponge.

TECHNICAL BULLETIN

If excess was left on tiles for several days, you may need to use SANITEN Heavy Duty Cleaner / Water based sealers Remover PD1010 to remove colorant on tiles. Curing time: 15 to 30 days Allow good ventilation during the drying and curing period. Do not scrub and /or wash colored surface before 30 days

PRODUCT LIFE EXPECTANCY

Product life: 5 – 10 years Subject to frequency of cleanings and type of cleaners used for maintenance of grout. Life span of the colorant may be enhanced with the application of SANITEN Grout Sealer S100 on the joints.

COVERAGE :

Varies with the porosity and the texture of the surface and the method of application 225ml should seal joints in a $300ft^2$ ($30m^2$) covered with 12x12 tiles and $\frac{1}{4}$ inch wide grout joint (1 coat)

REMOVER :

Use SANITEN Heavy Duty Cleaner / Water based sealers Remover PD1010

PACKAGING:

CODESIZEPACKINGCCxx-02225mlCase of 12 bottles

CAUTION:

Keep out of reach of children MAY IRRITATE EYES Do not get in eyes. Do not swallow. Wearing of gloves and safety glasses is recommended during application.

HANDLING AND STORAGE :

Avoid from freezing. Store in original container, well closed in a dry area at room temperature. Shelf life: 2 years

TECHNICAL SUPPORT :

Refer to the web site www.saniten.ca or call 450-777-1536.

N.B. All information here above is accurate. But having no control over the conditions of utilization of the product, we cannot assume any responsibility, legal or other, in regards of the results and/or any prejudice derived from.

Revision date: February 26, 2011